




RSW-0310 S2910-H





HPOE

RG-S2910- 24GT4SFP-UP- H	24 10/100/1000M PoE/PoE+ 4 HPOE 4 1000M SFP	POE HPOE POE 1.XX 2.XX 90W 3.XX 60W
RG-PBOX-DC12	RJ45 POE DC12V	

HPOE

HPOE
RG-PBOX-AC24

RG-S2910-24GT4SFP-UP-H
RG-PBOX-DC12
POE

POE



Contents




I




I



I




19




PBOX

(
4





PBOX






PBOX

PBOX
PBOX

M4*20mm





RG-PBOX

Data Out

PD

HPOE

1-4

Data&Power in

1m

18AWG

RG-

PBOX-DC12

CCD

C/CS



1



I



OT

OT




1	
2	
3	OT
4	

PE

PE


I



I



20



RG-PBOX

Data out

Data&Power in



HPOE

RG-PBOX-DC12

PBOX

A solid red horizontal bar is located to the left of the "Contents" text.

Contents





1 Console

2 Telnet/SSH

CLI

3 SNMP

CLI

4 WEB

WEB

admin/admin

| Console




PC

1

2

| Console



| Console




CLI



Ruijie>enable



| Console



?

11.X CLI

10.X

CLI

Ruijie#show version /show version slots / show cpu /show memory /show interface status /show ip route /show arp /show fan / show power /show temperature....

Ruijie#show run //

Ruijie(config-if-GigabitEthernet 1/1)#show this //

Ruijie#wr //

Ruijie#ping 8.8.8.8 //

Ping



Telnet




Telnet





Contents





1	FTP		
2	TFTP		FTP
3	USB	USB	5

FTP



1 FTP Server USB0 S6010 FLASH

```
Ruijie(config)#ftp-server username admin
Ruijie(config)#ftp-server password ruijie
Ruijie(config)#ftp-server topdir tmp:/
Ruijie(config)#ftp-server timeout 300
Ruijie(config)#ftp-server enable
```

2 PC FTP Client FLASHFTP FTP PC
S6010

3 PC FTP FTP Server

4 Upgrade USB

FTP


USB

USB
Upgrade

FTP

FTP
U

TFTP



1	PC	TFTP Server		PC	S6010
2	S2910	TFTP Client	TFTP	,	flash
	tmp		tmp		
	Ruijie#copy tftp://192.168.1.1/S2910_RGOS11.4(1)B3_02211500_install.bin				
	flash:/S2910_RGOS11.4(1)B3_02211500_install.bin				
3	Upgrade		upgrade		

TFTP

USB

TFTP

TFTP

USB
Upgrade

U

TFTP



FTP

FTP

TCP

TFTP

UDP

TFTP

www.ruijie.com.cn

www.ruijie.com.cn/service.aspx

support.ruijie.com.cn

webchat.ruijie.com.cn

4008-111-000