

| RG-AP720-A



| RG-AP720-A



RG-AP720-A




I AP RG-AP720-A





Ω

Ω





```
Ruijie(config)# Hostname xxx
```

telnet :

```
Ruijie(config)#Line vty 0 4
```

```
Ruijie(config-line)# password xxx
```

```
Ruijie(config-line)# login
```

```
Ruijie# clock set xxx
```

```
Ruijie# show clock
```




Enable

Ruijie(config)# enable password xxx

():

Ruijie(config-if)# description xxx



IP

```
Ruijie(config)# interface gigabitethernet xxx
```

```
Ruijie(config-if)# no switchport
```

```
Ruijie(config-if)# ip address 192.168.1.1 255.255.255.0
```

```
Ruijie(config-if)# no shutdown
```

```
Ruijie(config-if)# end
```

:

```
Ruijie(config)# ip route 192.168.1.0 255.255.255.0 10.1.1.1
```

```
192.168.1.0
```

```
10.1.1.1
```

☺ www.ruijie.com.cn

☺ www.ruijie.com.cn/service.aspx

☺ support.ruijie.com.cn

☺

